

IN THE SPECIFICATION

Beginning on page 10, lines 5-11, please amend the paragraph as follows:

Next, if the supply of current to the solenoid portion 2 is stopped, the moving core 33 is returned by a biasing force of the return spring 38 to ~~open~~close the supply valve seat 15 and ~~close~~ open the discharge valve seat 16 at the same time. As a result, the valve seat body 12 is moved toward the valve member 20 by fluid pressure of the passage 14, the valve seat body 12 abuts against the stopper section 21, and the valve seat body 12 is ready for opening with small stroke of the moving core 33.